GEIGER

Taper[™] Chair

Seat Height LOWER RIGHT SIDE OF SEAT



TO RAISE Take your weight off chair, lift tab up.

TO LOWER Lift tab up while seated.

At the proper height, your feet should rest flat on the floor with upper and lower leg forming a 90 degree angle.



Forward Tilt

TO ENGAGE Recline and flip lever down.

TO RELEASE Recline and flip lever up.

Engage forward tilt to support the thigh's declined posture when performing intensive tasks, such as keyboarding.

Note: When using forward seat angle, increase seat height slightly for added comfort.

Harmonic[™] Tilt Tension KNOB BELOW RIGHT FRONT SIDE OF SEAT



TO INCREASE Turn knob clockwise.

TO DECREASE Turn knob counterclockwise.

Set the tilt tension to control the resistance you feel when reclining.

Tilt Limiter vertical tab on left front side of seat

HORIZONTAL TAB ON LEFT FRONT SIDE OF SEAT



TO RELEASE

Lean forward and press lever back.

Engage the tilt limiter when you want to sit in an upright or partially reclined position.

800.456.6452 geigerfurniture.com © 2019 Geiger